

Lab – Simulate Creating a Disk Image for a Forensic Analysis


Overview

In this short lab, you will learn how to attach a disk to a SATA controller in VirtualBox that will represent a suspect's hard drive. You will then use your Kali Live (Forensic Mode) virtual machine to acquire the disk and create a forensic copy of the disk to later be analyzed.

Download the needed image file


We first need to download the VirtualBox disk from the Internet using the following URL.

www.mikemurphy.com/forensics/lecture.vdi




The following location is available in the event the download location for the VDI is no longer available

Backup location for the [Lecture.vdi](http://www.mikemurphy.com/forensics/lecture.vdi) Click on the open link and from the content menu, select download.




Launch your installation of VirtualBox


From the left-hand window pane of your VirtualBox manager, right click on the name of your Kali Live (forensic Mode) virtual machine and from the context menu, select **settings**.




From the left windows pane of your settings menu, click on **Storage**.




Under storage Devices, highlight your **Controller: SATA** controlling your Kali Live (Forensic Mode) VDI and then click on the plus (+) icon to add a hard disk. From the pop-up window, click on the **Choose existing disk**.




On the next screen, click on the plus (+) icon to browse and attach the lecture.vdi image previously downloaded.



Use the next window to browse to the save location for the downloaded lecture.vdi file. Once you find the file. Just x2 click it to finish the wizard.




Note that the lecture.vdi is now attached to the same SATA controller as the Kali Live (Forensic Mode) vdi. This is the equivalent of attaching the image as a new disk to a physical computer.




Launch your Kali Live (Forensic Mode) Virtual Machine


From the Left windowpane of your VirtualBox manager, launch your Kali Live virtual machine. If the Kali ISO image is no longer present in your VirtualBox CD/DVD drive, from the taskbar, click on devices, optical drives and select the name of your Kali ISO image.



Next, click on Machine and from the context menu, click on reset.



When the virtual machine rests, you will be present with the Kali boot menu. From the list of options, select Live (Forensic Mode)




Allow the machine to boot to the desktop. Once the machine boots to the desktop, open a terminal window.




In Linux, to look at all the hard drives that are attached to the system or to see which hard drives are attached to the SATA controller we can use the following command.

```
ls /dev/sda*
```



To see all the hard drives that are attached, we can use the following command.


```
ls /dev/sd*
```



```
root@kali: ~  
File Edit View Search Terminal Help  
root@kali:~# ls /dev/sda*  
/dev/sda  
root@kali:~# ls /dev/sd*  
/dev/sda /dev/sdb /dev/sdb1  
root@kali:~#
```

Our target disk to image is the /dev/sdb and we can confirm this by using the fdisk command to check the partitions of the drives attached to our SATA controller.

At the terminal prompt, type: `sudo fdisk -l`



```
root@kali: ~  
File Edit View Search Terminal Help  
root@kali:~# sudo fdisk -l  
Disk /dev/sdb: 4 MiB, 4194304 bytes, 8192 sectors  
Disk model: VBOX HARDDISK  
Units: sectors of 1 * 512 = 512 bytes  
Sector size (logical/physical): 512 bytes / 512 bytes  
I/O size (minimum/optimal): 512 bytes / 512 bytes  
Disklabel type: gpt  
Disk identifier: 8454CE98-8548-4079-BF92-45972FB2A026  
  
Device      Start   End Sectors Size Type  
/dev/sdb1   2048   8158     6111    3M Microsoft basic data  
  
Disk /dev/sda: 10 GiB, 10737418240 bytes, 20971520 sectors  
Disk model: VBOX HARDDISK  
Units: sectors of 1 * 512 = 512 bytes  
Sector size (logical/physical): 512 bytes / 512 bytes  
I/O size (minimum/optimal): 512 bytes / 512 bytes  
  
Disk /dev/loop0: 2.55 GiB, 2725785600 bytes, 5323800 sectors
```

We are currently working at the root of our Kali Live desktop. Unless we tell Kali different, anything we save will be saved to the root of our Kali machine.

We need to create a low-level forensic image using the dd command line utility.

dd is a command-line utility for Unix and Unix-like operating systems, the primary purpose of which is to convert and copy files.

At the terminal prompt I type the following command. The drive identified as sdb is my attached drive of just under 5 MB.

```
dd if=/dev/sdb of=forensic.img
```

if stands for **input file**

of stands for **output file**.

forensic.img is the name we have given to the output file. Since the forensic image is so small, once we hit enter, the results come right back to the prompt.

```
root@kali: ~  
File Edit View Search Terminal Help  
root@kali:~# dd if=/dev/sdb of=forensic.img  
8192+0 records in  
8192+0 records out  
4194304 bytes (4.2 MB, 4.0 MiB) copied, 0.0367567 s, 114 MB/s  
root@kali:~#
```

Since we are doing everything from within the root directory, our forensic image file is automatically saved to the same location. To see the forensic image we created and saved to the root directory, at the terminal prompt type, **ls**.

```
root@kali: ~  
File Edit View Search Terminal Help  
root@kali:~# ls  
Desktop Downloads Music Public Videos  
Documents forensic.img Pictures Templates  
root@kali:~#
```

Everything in blue is a directory. Our forensic.img is a file so it is shown using a white font. We created this file in memory so if we shut or reboot our Kali Forensic Mode virtual machine, we must recreate the image again using the same dd command.

Summary

We cannot save the forensic image to any location inside of our Kali Forensic Mode machine. As it is, the forensic image is stored in virtual memory so when we power down the live CD, everything will be lost. In a real-world situation, we would have saved the output file to an external drive. In the real world where we have seized a suspect's hard drive, we would prefer to make the forensic image back at the lab where we have the tools and storage available. A seized hard drive of 2 or 3 TBs could take days or even weeks to image.

In our next lab, we will use Autopsy to examine the forensic image we have made. If you lose the image while powering down the Kali Forensic Mode machine, you can quickly create another using the same dd command.

End of the lab!

